



REICHARD'S Performance Center

W188 N10707 Maple Rd. • Germantown, WI 53022 • (414) 251-8472



POLARIS FOX SKI SHOCKS Part #'s 4888,4754,4889,4890

Remove the old shocks. Install the Fox shocks with the air valve up and facing into the inside of the bulkhead. (This will be upside down from stock) Use one washer on each side at the top mount. Let the shock fall where it wants to and space the bottom as required. Make sure the bushings pivot free and are well greased.

The standard installed spring length is 8 3/4" long. You can preload the spring more or less depending upon your individual riding style.

Remember ... Fox shocks are completely rebuildable.