



REICHARD'S Performance Center

W188 N10707 Maple Rd. • Germantown, WI 53022 • (414) 251-8472



#4406, #4744 SRV, V-MAX, EXCITER II
FRONT OF REAR SUSPENSION FOX SHOCK

Remove the suspension and front shock. Install the stock bushings and collars in the new shock. Install the new shock with the air valve up. Move suspension arm up and down to make sure the shock doesn't contact anything.

Remember ... Fox shocks are completely rebuildable.