

REICHARD'S PERFORMANCE CENTER

W188 N10707 MAPLE ROAD
GERMANTOWN, WI 53022
PHONE : 414-251-8472
FAX : 414-251-9669

#4674 SRV EXP COMET CLUTCH KIT
For 0-3000 Feet elevation

1. Remove the primary clutch then remove the six bolts from the outer cap. Remove the original spring and weights.
2. Inspect the primary clutch weights, pins, rollers, and bushings for wear. Clean and replace any worn parts. Remove any shine from the clutch sheaves with a medium grade sandpaper then thoroughly clean the belt surfaces with lacquer thinner. Lube all moving parts with Comet Lube except the moveable sheave bushing and cap bushing.
3. Reassemble the primary clutch installing the new supplied primary spring and weights.
4. Remove the secondary clutch and disassemble by removing the snap ring from behind the helix cam.
5. Clean and check all parts for wear, especially the nylon slider buttons. If they show any wear replace them. Remove any shine from the clutch sheaves with a medium grade sandpaper then thoroughly clean the belt surfaces with lacquer thinner.
6. The stationary sheave has two brass bushings pressed in. You should repack with low temp grease between these two bushings.
7. Adjust the belt shims in the center of the clutch so that the belt is flush with the top of the sheaves.
8. Set the spring position to B1 and prewind to 30 degrees.

Note: Proper shift RPM range is 6900-7200. This clutch kit has been tuned with a factory Yamaha belt. Any other brand will cause a performance loss.