



# REICHARD'S Performance Center

W188 N10707 Maple Rd. • Germantown, WI 53022 • (414) 251-8472



## #4421 V-MAX 4 DIGITAL CDI IGNITION

1. Remove clutch side panel.
2. Unbolt and remove the plate that the stock CDI box is mounted to.
3. Remove the two screws that secure the stock CDI to the plate.
4. Screw the new CDI box to the original mounting plate using the original bolts and reattach to sled. Use a little loctite on the threads.
5. Reconnect all connections making sure that the wires are securely into the plugs.

### NOTES

This ignition can also be used without the stock charging system by running a 12 volt battery as a total loss system. If this is desired for racing, please call for additional instructions. Many program chips with either a 90 degree or 180 degree firing order are available from us, please call for information.

Thank You ... Have Fun And Hang On !!!